MASTER INDEX

The following pages contain the XVM/RSX master index. This master index is a result of merging the indexes of all the document PARTs.

The format of the index entries is:

Topic, part no.-page no.

Example:

QJOB, V-2-29

Interpretation:

Page 2-29 of PART V discusses QJOB.

Abbreviations for commands, VII-1-9
ABORT, IV-2-2, VI-2-5, VI-3-11, VI-65, VI-9-6, VI-12-8, VI-13-8, VI-18-1, VIII-6-4
ABORT command, VIII-6-4
Aborting I/O for task, VI-2-5, VI-3-11, VI-6-5, VI-9-6, VI-12-8, VI-13-8
Aborting task execution, IV-2-2
ACD, TDV Function task, VII-24-1, VII-5-4, VIII-6-3
ACI, TDV Function task, VII-24-1, VIII-5-2, VIII-6-3
Active Task List (ATL), II-1-4, III-1-9, IV-2-2, IX-2-3
Activating task, II-1-4
Activating task execution, IV-2-57
AD conversion,
  starting, VI-14-12
  stopping, VI-14-13
AD handler,
  requests, VI-14-1
  task, VI-14-1
ADCON, VI-14-4
Adding a new device, IV-2-9
Adding a task, IV-2-35
Adding tasks, XII-5-1
ADDIS, VI-14-5
ADRMAP, VI-14-15
ADRSET, VI-14-9
ADSMAP, VI-14-14
ADSSET, VI-14-6
ADSTOP, VI-14-13
ADSTRT, VI-14-12
ADV, IV-2-9
Advanced task,
  construction, XI-1-1
  development, II-4-2
AF handler,
  requests, VI-15-1
  task, VI-15-1
ACF I/O functions, VI-15-2
AFT, VI-1-2
AI, VI-15-3
Alias-execute option, V-2-18
Allocate, Vi-6-6
Allocation of I/O buffers, XI-6-1, XI-6-2
Allocation of space, X-2-3
Altmode, IV-1-2, IV-2-38, IV-2-59, VII-1-8, VII-6-3, VII-6-9, XI-2-1, XI-3-2
Altmode character, X-2-6
Analog channels,
  reading sequence of, VI-15-3
Analog output--A633 modules, VI-16-4
Analog-to-digital converter I/O, VI-14-1
  functions, VI-14-2
ANY subroutine, X-2-15, X-3-6
AO, VI-16-4
API level, II-1-4
API level light, II-1-4
API lines, V-2-5
Arguments, X-2-2
Arrays, X-2-1, X-2-15
  size of, X-2-2
ASCII string, X-2-5
ASCII to BCD conversion, VI-8-18
ASCII to EBCDIC conversion, VI-8-19
ASP, IV-2-12
Assembler options, VII-3-2
Assembling a MACRO program, VII-3-1
Assembly parameters, III-B-1, III-C-1, X-D-1
Assigning a partition, IV-2-12
At Sign (@), IV-1-3, VII-1-9
ATTACH, VI-2-6, VI-7-3, VI-18-2
Attach Flag Table (AFT), VI-1-2, IX-4-1
ATTACH macro, VI-B-4
Attaching I/O device, VI-2-6
Automatic flying capacitor scanner I/O, VI-15-1
  functions, VI-15-2
Automatic priority interrupt (API), V-2-4
AUTORM, IV-2-32, IV-2-59, V-2-17, IX-2-8.1
Auxiliary disk functions, VII-2-3

Backarrow (←), VII-1-9, VII-7-3
Backing up a system, IV-2-59
Backslash (\), IV-1-3, VII-1-9
Backspacing,
  files, VI-8-4
  records, VI-8-5
Bank-mode option, VII-6-7
Basic Task Builder (BTK), VII-6-1, VII-6-18
BATCH, VIII-1-1, VIII-6-2
  load command, VIII-4-3
  operator interaction, VIII-4-1
  special commands, VIII-2-2, VIII-3-1
  states, VIII-4-1, VIII-4-2
  use, VIII-2-1
Batch account file,
  display, VII-24-1, VIII-5-4, VIII-6-3
  initialization, VII-24-1, VIII-5-2, VIII-6-3
  organization, VIII-5-1
Batch control for operator, IV-2-41
Batch file editing, VII-5-1
Batch job,
  queuing, V-2-29
Batch job file, VIII-6-7
  running, XII-3-4, XII-3-7
  submission, VIII-2-1

Batch mode, VII-3-1
  FORTRAN, VII-2-1
  MACRO Assembler, VII-3-1
  processing, VII-13-1, VII-14-1, VII-15-1
Batch processing, II-1-3, II-3-3, II-4-2, VIII-1-1
  example, VIII-1-2
  introduction, VIII-1-1
  invoking, VIII-2-1
  sequence sample, VIII-1-1
  sources, III-B-15
  terminating, VIII-2-3
Batch Processor (BATCH), VIII-1-1, VIII-6-2
Batch system, XII-3-6
  errors, VIII-B-1
  installation checklist, VIII-A-1
  management, VIII-5-1
  operations, VIII-6-1
  organization, VIII-6-1
Baud specification, IV-2-29
Beam position, X-3-2
Binary file,
  TSK extension, IV-2-35
Bit maps, VI-6-2
BLANK subroutine, X-2-13
BLINK, X-2-8
Block-mode editing, VII-4-1
Blocks,
  system COMMON, III-1-2, III-1-13
Bootstrap,
  Warm-Start, IV-2-60
Bootstrapping,
  DOS, IV-2-26
  RSX system, XII-4-1
Boundaries of core, X-2-2
Braces ({}), VII-1-10
Breakpoints in a task, VII-22-1
BSPFIL, VI-8-4
BSPREC, VI-8-5
BTK (Basic Task Builder), III-3-3
Buffer allocation and deallocation, XI-6-2
Buffer and partition size, VII-4-3
Buffer preallocation, XI-6-1
Buffers, IX-2-16, XI-4-2, XI-6-1
  within a partition, XI-6-4
BUILD, XII-3-1
  preparing to run, XII-3-1
  questions, XII-3-1
  running, XII-3-1
  termination, XII-3-4
Building process, XII-1-1
Building task for execution, VII-6-1
Building,
  XVM/DOS system, XII-2-1
  XVM/RSX V1B, XII-3-4
CAL,
  dispatch routine, V-1-2
  function code, V-1-2
  instructions, V-1-1
  service routines, V-1-2
CAL parameter block (CPB), V-1-1, VI-2-3, VI-2-6, VI-2-25
CALL DEFINE statement, VI-3-14
CANCEL, IV-2-13, V-2-2
CANCEL ALL command, VIII-4-7
CANCEL command, VIII-4-7
Cancelling mark-time requests, V-2-69
Cancelling requests for a task, IV-2-13
Cancelling task requests, V-2-2
Card punch handler,
  requests, VI-19-1
  task, VI-19-1
Card punch input/output, VI-19-1
  functions, VI-19-1
Card reader I/O, VI-10-1
  functions, VI-10-1
Carriage return IV-1-2, IV-2-38, VII-1-8, XI-2-1, XII-4-1
CC handler,
  requests, VI-17-1
  task, VI-17-1
CCLOSE routine, X-5-3
CD handler,
  requests, VI-10-1
  task, VI-10-1
CHAIN and EXECUTE programs, VII-6-4
Changing device assignment, IV-2-51
Character set, .SIXBT, V-C-1
Characters, nonprinting, X-2-6
Characters, upper/lower case, VII-1-10
Checkout package, XII-3-3
  running, XII-4-3
  sources, III-B-30
CINIT routine, X-5-3
CIRCLE subroutine, X-2-16
  example, X-2-19
Clearing interrupt line, VI-2-12, VI-3-11, VI-7-4
Clock, XII-4-1
Clock handler, IX-2-3
Clock Queue (CKQ), II-1-5, III-1-9, IV-1-13, IX-2-6
CLOSE, VI-2-7, VI-3-12, VI-7-3, VI-12-7, VI-13-6, VI-18-2, VI-19-2
CLOSE macro, VI-B-5
Closing a file, VI-2-7, VI-3-12 VI-7-3, VI-12-7, VI-13-6, VI-19-2
CNAME, X-2-2, X-2-4, X-2-5, X-3-4
Code modification routines, X-4-1
COMGET, VI-17-3
Comma, IV-1-2
Comma character, VII-7-2

Command,
  abbreviations, VII-1-9
  conventions, IV-1-3
  input line, XI-2-1
  syntax errors, SLIP, VII-5-16
Command string terminators, VII-1-8
Commands,
  BATCH, special, VIII-2-2, VIII-3-1
  MULTIACCESS Monitor, VII-1-2.1
  OPR, VIII-4-1, VIII-4-3
Comment, IV-1-3
COMMON, IV-2-14
COMMON blocks, II-1-5, VII-6-8, VII-6-10, VII-6-11
  system, III-1-2, III-1-13, IV-2-46
Common communicator I/O functions, VI-17-1
Comparing a record, VI-8-20
Compiling a FORTRAN program, VII-2-1
Compiler options, FORTRAN IV, VII-2-2
COMPUT, VI-17-5
Concepts, II-1-3
Configuration procedures, XII-4-1
CONNECT, V-2-4
Connecting AD to task, VI-14-4
Connecting buffer, VI-16-10
Connecting to interrupt line, V-2-4
Conserving space, IV-2-32
Console dialogue, X-9-1
Console listing, example, X-9-2
CONSTRUCT, IV-2-15
CONSTRUCT TDV Function task, VII-19-1
  error messages, VII-19-2
Construction of advanced tasks, XI-1-1
Contact interrupt digital input--W733 module, VI-16-9
Contact sense/interrupt digital input--W731, W733 modules, VI-16-7
Control-character facilities, VII-1-2.1
Control lines, VIII-2-2, VIII-6-7
Control records, SLIP, VII-5-4
Conventions,
  directive, V-1-3
  I/O handler construction, XI-4-1
  MCR task construction, XI-2-1
  TDV task construction, XI-3-1
Conventions for TDV command, VII-1-8
Conversion to XVM/RSX, VII-6-18
COPY subroutine, X-2-6, X-3-2
Core,
  allocation, III-1-6
  examining, IV-2-37
  management, III-1-1
  partitioned, II-1-5
  reconfiguration, IV-2-45
  sharing, V-2-53
  size, III-A-1, XII-4-1
Core boundaries, X-2-2
Core locations,
  examining, V-2-55
  modifying, V-2-57
Core partition, IV-1-1
  availability, IV-2-2, VI-1-3
  freeing, IV-2-37, V-2-67
Core space,
  exec-mode, III-1-14
  permanent, III-1-11
  semipermanent, III-1-13
  type of, III-1-11
  user-mode, III-1-11, III-1-16
CPB word, V-4-1
CREATE, VI-3-13
Creating random-access file, VI-3-13
CR03B handler,
  operation, VI-10-8
CR15 error messages, VI-10-3
Cross disk system, XII-1-1, XII-3-2
  building, XII-B-1
CTDI, VI-16-9, VI-16-10
CTRL/C, IV-1-1, VI-1-2, IV-2-14, IV-2-42, IV-2-70, VI-9-3, XI-2-1, XII-3-4
CTRL/D, VII-3-6
CTRL/P, VI-9-4
CTRL/Q, VII-6-3
CTRL/R, XII-3-4, XII-3-7
CTRL/T, VI-9-4, VII-1-7, XI-3-2, VIII-6-2
CTRL/U, VI-1-3, VII-1-9
CTRL/X, VI-9-4
CTRL/Y, IV-2-62.1, VI-9-4
Current task pointer, IX-3-2

DASH (dashed lines), X-2-8
Data modes, VI-1-8
  by device, VI-1-9
  legal, VI-9-2
Data records,
  random-access file, VI-3-4
  sequential-access file, VI-3-2
DATE, IV-2-16, V-2-8, VII-11-1
  entering, IV-2-31
DCLOSE routine, X-5-3
DEALLOCATE, VI-6-9
Deallocation of buffers, XI-6-2
Debugging,
  on-line, IV-2-37
Debugging with ODT, VII-22-2

DEC026 character set, VI-10-7
DEC029 character set, VI-10-6
DECtape Directory List,
  TDV Function task, VII-11-1
  error messages, VII-11-2,
    VII-11-3
DECtape handler, III-1-4
DECtape I/O, VI-7-1
  functions, VI-7-2
Default node assignments,
    III-1-11
Default priority of task,
    VII-6-8
Default values, XII-3-7, XII-4-1
Deferred-execute option,
    V-2-18.1
Defining terminal character-
    istics, IV-2-29
DELETE, VI-2-9, VI-3-11
Delete character or line,
    VII-1-9
DELETE FILE error messages,
    VII-8-2
DELETE FILE, TDV Function task,
    VII-8-1
DELETE macro, VI-B-5
DELETE routine, X-4-2
Deleting a task, IV-2-54
Deleting file name from
    directory, VI-3-11
Deleting files, VI-2-9
Deletion, IV-1-3
Delimiter, IV-1-2
Delimiters, VII-7-3
DEQ, IV-2-17
  list symbols, IV-2-17
  listing abbreviations,
    IV-2-18
Deque, II-1-4
Deque list, IX-1-1
DETACH, VI-2-11, VI-7-3,
    VI-18-2
DETACH directive, XI-4-2
DETACH macro, VI-B-4
Device,
  adding a, IV-2-9
Device assignment,
  changing, IV-2-51
Devices, IV-2-10, IV-2-24
    VI-1-5
  I/O, VII-1-6
Devices and assignments, IV-2-23
Devices and assignments list,
    IV-2-51
DFDI, VI-16-9, VI-16-12
DI, VI-16-7
Dialogue, TKB, VII-6-17
Differences between XVM/RSX
    and RSX PLUS III, II-1-2
Digital output latching--M685,
    M803, M805 modules, VI-16-6
Digital output, single shot--
    M687 and M807 modules,
    VI-16-5
DINIT routine, X-5-2
Directive errors, V-1-2
DIRECTORY LIST, TDV Function
    task, VII-10-1
  error messages VII-10-2,
    VII-10-3
DISABLE, IV-2-25, V-2-10
Disabling a task, IV-2-25, V-2-10
Disabling file-oriented I/O,
    IV-2-27
DISCONNECT, V-2-12, VI-2-12,
    VI-3-11, VI-7-4
Disconnecting AD from task,
    VI-14-5
Disconnecting buffer, VI-16-12
Disconnecting from an interrupt
    line, V-2-12
Disk addresses, VI-4-1
  RK, VI-4-1
  RP, VI-5-1
Disk blocks, IV-2-54
Disk block number, VI-6-1
Disk,
  configuration, II-2-4
  directory, VII-10-1
  support, II-2-3
Disk-to-disk editing, VII-4-3
Disk driver I/O, VI-6-1
  functions, VI-6-4
Disk driver,
  requests, VI-6-3
  tasks, VI-6-1
Disk errors, VI-6-3
Disk file I/O, VI-3-1
Disk I/O buffers, III-1-7
  size, III-1-7
Disk parameters, IX-3-4
Disk platters,
  RK, VI-4-1
  RP, VI-5-1
Disk registers,
  examining, IV-2-37
Disk, task storage on, VII-19-1
Disk-UFD table, IV-2-27, IV-2-36
DISMOUNT, TDV Function task, VII-17-1
  error messages, VII-17-1
Dismount tape, VII-7-4
Dismounting a disk, IV-2-27
Dismounting a disk, (logically),
    VII-17-1
Dismounting tape, VI-8-12, VI-8-13
DISPAT partition, III-1-5
Dispatcher, MCR, IV-1-1
Display file, X-2-2, X-2-3
Display parameter settings, X-2-10
Documentation, II-4-1
DOL, VI-16-6
$ command, VIII-3-7
-$ command, VII-5-5
Done bit, IV-2-32
DOS, IV-2-26, VI-16-5
DOS batch job file,
  generating, XII-3-1
Dots, XI-3-1, XI-4-1
DQRQ, VI-2-5
Driver call, VI-6-4
DSKAL macro, VI-B-1
DSKDAL macro, VI-B-2

DSKGET, VI-B-2
DSKPUT macro, VI-B-2
DSM, IV-2-27
DSM, TDV Function task, VII-17-1
DT handler,
  requests, VI-7-1
  task, VI-7-1
DTC, IV-2-29
Dump mode, VII-3-6
DYLINK routine, X-6-2
Dynamic reconfiguration, II-1-5
DYSET-DYLINK, example, X-6-4
DYSET routine, X-6-1

Editing batch files, VII-5-1
Editing disk-to-disk, VII-4-3
Editor, VII-4-1
  error messages, VII-4-3, VII-4-4
$EJECT command, VIII-3-6
Embedded subroutines, X-6-3
ENABLE, IV-2-25, IV-2-30, V-2-14
Enabling file-oriented I/O, IV-2-36
$END command, VIII-3-8
END-OF-FILE, VII-5-14
  SLIP, VII-5-5
End-of-file pointer, X-2-2
ENTER, VI-2-13, VI-3-10, VI-7-3, VI-18-2
ENTER macro, VI-B-4
Entering register restore routine, V-3-3
Entering register save routine, V-3-2
Entering time and date, IV-2-31
Environment, II-1-1
EOT, VI-8-8
ERROR CLOSE, VI-3-16
Error codes for *FILE routine, VII-5-15
$ERROR command, VIII-3-10
Error flags, MACRO Assembler, VII-3-7
Error messages, IV-3-1, X-A-1, XII-4-3
  CONSTRUCT, VII-19-2
  CR15, VI-10-2
  DECTAPE DIRECTORY LIST, VII-11-3
  DELETE FILE, VII-8-1
  DIRECTORY LIST, VII-10-3
  DISMOUNT, VII-17-2
  EDITOR, VII-4-3, VII-4-4
  FORTRAN, VII-2-5
  INSTALL, VII-13-3
  MACRO Assembler, VII-3-9
  MOUNT, VII-16-2
  NEW DIRECTORY, VII-12-2
  ODT, VII-22-10
  OPR, VII-4-10, VIII-4-9
  OTS, VII-2-15, VII-2-17
  QUEUE, VII-21-4
Error messages (cont.)
  REMOVE, VII-15-2
  RENAME FILE, VII-9-2
  REQUEST, VII-14-2
  SLIP, VII-5-14
  TDV, VII-7-5
  TKB, VII-6-19
  UC15, VI-10-5
Error recovery, VI-8-17
  handler, VI-8-17
  user, VI-8-17
Errors,
  batch system, VIII-B-1
  $SLIP control record, VII-5-15
  SLIP sequencing, VII-5-16
  TKB recoverable, VII-6-20
Errors, directive, V-1-2
Establishing random links, VI-14-9
Establishing sequential links, VI-14-6
ETIME, IV-2-31
Event variable, V-1-2
  setting, V-2-24
  waiting for, V-2-71
Event variables, V-4-1, VI-1-7, VI-A-1
  returned, V-4-3, VI-A-2
  special meanings, VI-A-5
Examining core, IV-2-37
Examining core locations, V-2-55
Examining disk registers, IV-2-37
Example of batch processing, VIII-1-2
Examples, VI-18-4
  CIRCLE subroutine, X-2-19
  console listing, X-9-2
  DYSET-DYLINK, X-6-4
  FORTRAN, X-9-6
  four-square display, X-2-18
  MACRO programming, X-7-6
  PRAMTR settings, X-2-25
  ROTATE subroutine, X-2-26
  sine wave, X-2-20 through X-2-23
  writing tablet, X-8-3
Exceeding time limit, VIII-4-8
EXEC mode, III-1-2, IV-2-2, XI-3-1
  core space, III-1-14
EXECUTE, IV-2-32, V-2-16
Execute List (EXELH), III-1-9, IX-2-8
Execution of Resident MCR, IV-1-1
Executive-mode option, VII-6-7
Executive, II-1-3, II-3-2
  placement, III-1-2
  replacing XII-A-1
  sources, III-B-28
EXELH, IV-2-32
EXIT, IV-2-2, V-2-19, VI-2-12, VI-3-11, VI-7-4
EXIT command, VIII-4-7
Exit Processor, MULTIACCESS, V-1-3
External links, VII-6-14
EXU.13, VII-6-13

F option, VII-7-3
FAC (Fetch-A-Character), IV-1-2
Fetch-A-Character (FAC)
    subroutine, XI-2-1
File,
  creation date, VII-10-2
  size, VII-10-2
  transfer, VII-7-3, VII-7-4
*FILE errors, VII-5-14
File name and extension,
    VII-10-2
File name format, X-2-2
File name list, VII-6-13
*FILE records, VII-5-4
*FILE specification, SLIP,
    VII-5-3
Files, XI-1-2
FIN, TDV Function task, VII-7-2
FININS, IV-2-32, IX-2-8.1
Fix, IV-2-34, V-2-22
Fixing a task, V-2-22
  in core, IV-2-34
Flicker, X-2-9
Floating point, XII-3-2, XII-3-6
Floating-point exit register,
    V-2-52
Floating-point processor (FPP),
    VII-2-1, VII-2-4
FORCE command, VIII-4-7
Form feeds, VII-7-3
FORMAT, VI-8-6
Format of information returned
    by READ, VI-18-2
FORTRAN,
  error messages, VII-2-5
  examples, VI-18-4, X-9-6
  interface, VI-16-3
  line numbers, VII-5-10
  other versions, VII-2-3
  program compilation, VII-2-1
FORTRAN IV Compiler, II-3-3
  options, VII-2-2
FOU, TDV Functions task, VII-7-2
Four-square display example,
    X-2-18
FPP system OTS error messages,
    VII-2-17
Free blocks, VII-11-1
Free core, XI-6-2
Freeing attached I/O device,
    VI-2-11, VI-7-3
Freeing a core partition, IV-2-73,
    V-2-67
Freeing storage, VI-6-9
Front-End Interrupt Driver task
    (VPVEC), XI-5-1
FSPEOT, VI-8-8
FSPFIL, VI-8-9
Function of system directives,
    V-1-1
Function tasks, TDV, VII-1-2
Functions,
  task development, III-1-5

GARBAGE COLLECTION, XI-6-3
Generating DOS batch job file,
    XII-3-1
GET, VI-6-12, VI-7-5
GET functions, X-7-3
GETBLT routinee, X-8-1
GETPSH routine, X-5-5
Getting on the air, X-9-1
GO command, VIII-4-6
GRAPH subroutine, X-2-11, X-3-5
Graphics system, II-4-2
Guidelines for advanced task
   construction, XI-1-2

Handler,
  exit, VI-1-7
  initialization, VI-1-6
  recovery, VI-8-17
Handler internal closing of file,
    VI-3-16
Hardware, II-1-3, X-1-2
  expanded, II-2-2
  minimum, II-2-1
  interrupts, XI-4-2
  registers, XI-1-2
Hardware existence flags, IX-3-5.1
Header word, XI-6-2
HINF, VI-2-15, VI-3-10, VI-6-4,
    VI-7-2, VI-8-3, VI-9-5,
    VI-10-2, VI-11-2, VI-12-2,
    VI-13-2, VI-14-2, VI-15-2,
    VI-16-2, VI-17-2, VI-18-2,
    VI-19-1, VIII-6-3
HINF macro, VI-B-5
Historical system information,
    VII-23-2
HLD, IV-2-43
HOLD command, VIII-4-6
Hollerith card code,
  type 26 punch, VI-10-7
  type 29 punch, VI-10-6
Hollerith data statements,
    X-2-5

IFAC subroutine, XI-2-1
IFAC (Initialize Fetch-A-
    Character), XI-1-2
Image ALPHA, VI-11-1
Image ASCII, VI-1-8
  mode 3, VI-8-23, VI-8-27,
    VI-9-8, VI-9-10, VI-12-6,
    VI-13-5, VI-13-7
Image binary, VI-1-8
    mode 1, VI-8-22, VI-8-26,
    VI-12-3, VI-13-4, VI-13-7
IMAGE mode, VII-7-3
Index register (XR), VII-6-7
Initialize FORTRAN I/O tables,
    VII-2-4

Initializing the account file, VIII-5-2, VIII-6-3
Initializing floating-point exit register, V-2-52
Initiating time slicing, IV-2-63
Input lines, IV-1-2
Input/output, VII-2-3
  CONSTRUCT, VII-19-1
  DECTAPE DIRECTORY LIST, TDV Function task, VII-11-2
  DELETE FILE, VII-8-1
  DIRECTORY LIST, TDV Function task, VII-10-2
  DSM, VII-17-1
  EDITOR, VII-4-2
  FORTRAN IV, VII-2-4
  INSTALL, TDV Function task, VII-13-2
  MACRO Assembler, VII-3-5, VII-3-6
  MOUNT, VII-16-1
  QUEUE, VII-21-3
  REMOVE, VII-15-1
  RENAME FILE, TDV Function task, VII-9-2
  REQUEST, VII-14-1
  SLIP, VII-5-14
  STATUS, VII-23-1
  Task Builder, VII-6-4
  TDV function tasks, VII-7-3
Input/output operations, II-4-2
Input/output routines, X-5-1
INSERT, VII-5-6, VII-5-7
Insertion records, SLIP, VII-5-4
INSTALL, IV-2-35
INSTALL, TDV Function task, VII-13-1
  error messages, VII-13-3
Installation checklist, batch system, VIII-A-1
Installation Guide, II-4-2
Installing a task on a user disk, IV-2-15
Integer event variable (IEV), X-8-1
INTENSITY, X-2-7
INTENTRY, V-3-1, V-3-2
Internal interrupt routine, XI-5-1
Internal links, VII-6-14
Interrupt line,
  connecting to, V-2-4
  disconnecting, V-2-12
Interrupts, XI-1-2
Interval ranges, IV-2-57, IV-2-61, IV-2-68, V-2-24, V-2-42, V-2-60
INTEXIT, V-3-1, V-3-3
Introduction, IV-1-1, V-1-1, VI-1-1, VII-1-1, XII-1-1
  to software capabilities, II-3-1
  to XVM/RSX, II-1-1
Invoking,
  batch processing, VIII-2-1
  construct, vii-19-1
  core sharing, V-2-53
  DECTAPE DIRECTORY LIST, VII-11-1
Invoking (cont.)
  DIRECTORY LIST, VII-10-1
  DISMOUNT, VII-17-1
  FIN, DEC, FOU, LIS and TYPE, VII-7-2
  FORTRAN IV Compiler, VII-2-1
  INSTALL, VII-13-1
  MACRO Assembler, VII-3-2
  MOUNT, VII-16-1
  NEW DECTAPE DIRECTORY LIST, VII-12-1
  ODT, VII-22-2
  QUEUE, VII-21-1
  REMOVE, VII-15-1
  REQUEST, VII-14-1
  SLIP, VII-5-2
  STATUS, VII-23-1
  Task Builder, VII-6-2
  Text Editor, VII-4-1
I/O,
  disabling file-oriented, IV-2-26
  enabling file-oriented, IV-2-36
I/O buffers, XI-1-2, XI-4-2, XI-6-1, XI-6-4
I/O data modes, VI-1-8
I/O device handler,
  sources, III-B-18
  tasks, III-1-4, III-1-13
I/O device handler task, II-1-3, II-3-4, III-1-4, III-1-13, VI-1-4
  example, XI-4-4
I/O devices, VII-1-6
I/O devices and codes, VI-2-17
I/O functions, VI-2-1, VI-2-2, VIII-6-3
I/O handler construction, XI-4-1
I/O handler task priority, IV-2-4
I/O handler tasks, reentrant routines for, IX-3-8
I/O handlers, XII-3-3
I/O request, III-1-9
  processing, VI-1-7
  queuing, VI-1-6
I/O Rundown, IV-2-2, XI-4-2
I/O Rundown Queue (IORDQ), III-1-9, IX-2-9
I/O Rundown task and Queue, VI-1-3
I/O tables, lists, and tasks, VI-1-1
IOPS ASCII, VI-1-8
  mode 2, VI-8-22, VI-8-26, VI-9-7, VI-9-9, VI-11-1, VI-12-5, VI-13-4, VI-13-7, VII-7-3
IOPS binary, VI-1-8
  mode 0, VI-8-22, VI-8-26, VI-12-3, VI-13-3, VI-13-7
  modes, VI-18-3
IOPS binary data mode, VII-7-3
IORDQ, VI-1-3
IORD, VI-1-4, VI-9-6

$job command, VIII-3-1
JOB LIST command, VIII-4-5
Job processing, prevention of, VIII-4-7
Job requests, removal of, VIII-4-8
Job selection, VIII-6-5
Job Startup Processor (JOB...), VIII-6-2
Job Termination Processor (END...), VIII-6-2

KILL command, VIII-4-8

LABEL, VI-8-11
Large Node Description List (LNDL), IX-2-12
Level,
  API, II-1-4
  mainstream, II-1-4
  task, II-1-4
Library files, VII-6-13
Library routines, VII-6-13
Light pen, X-5-3
LIGHT PEN ENABLE, X-2-8
Line formats supported, VI-11-1
Line printer handler, III-1-4
Line printer I/O, VI-11-1
  functions, VI-11-2
LINE subroutine, X-2-4, X-3-3
Line-by-line mode editing, VII-4-1
LINK definitions, VII-6-14
Linkages, VII-3-1
Links and structures description, VII-6-13
LIS, TDV Function task, VII-7-2
List options, Task Builder, VII-6-4
List system deques, IV-2-66
Listheads, IX-2-8
Listing output, XI-2-1
Listing system deques, IV-2-17
LOG, IV-1-3
$LOG command, VIII-3-5
Logical unit number, XI-4-1
Logical Unit Table (LUT), VI-1-1, XI-4-1
Lowercase characters, VII-1-10
LP handler,
  requests, VI-11-2
  task, VI-11-1
LP11, XII-3-6
LPOOL (Pool of Empty Large Nodes), IX-1-2
LTORPB routine, X-5-3
LUN, VI-1-1, VI-2-3
  deassigning, IV-2-51
  mapping, V-2-34, VI-2-3
LUN assignments,
  Editor, VII-4-2
  FORTRAN IV, VII-2-3
  MACRO Assembler, VII-3-5
  TDV function tasks, VII-1-4
LUN-0, VI-2-5
LUN-2, IV-1-1, IV-1-3, IV-2-52
LUN-3, IV-1-3, IV-2-14, IV-2-16, IV-2-42, IV-2-52, IV-2-70, V-1-3
LUN-5, IV-2-35
LUN-6, VIII-A-2
LUN-7, VIII-A-2
LUN-8, VIII-A-1
LUN-10, VIII-5-3, VIII-5-4
LUN-16, IV-2-17, IV-2-66, VIII-5-4
LUNs, IV-2-23
  number of, XII-3-3, XII-3-7
LUN-UFD table, IV-2-27, IV-2-36
LUT, IV-2-36, VI-1-1

MACRO Assembler, II-3-3
  error flags, VII-3-7
  error messages, VII-3-9
  other versions of, VII-3-6
Macro definitions file, V-A-1, VI-B-1, VII-3-6
MACRO program assembly, VII-3-1
MACRO programming X-7-5
  example, X-7-6
Magtape handler, III-1-4
Magtape I/O, VI-8-1
  functions, VI-8-2
Magtape operation, VII-7-4
Main display file routines, X-3-1
Mainstream level, II-1-4
Mapped LUNs, V-2-35.1, VI-1-2
Mapping random input parameters, VI-14-15
Mapping sequential input parameters, VI-14-14
MARK, V-2-24
Master File Directory (MFD), IV-2-36, IV-2-53
MCR, III-1-3
  Dispatcher, IV-1-1
MCR function task, IV-1-1, IV-2-1
  example, XI-2-2
MCR interaction, XI-2-1
MCR OPR command (...OPR), VIII-6-3
MCR (Monitor Console Routine) communications, IX-3-3
MCR partition size, XII-4-2
MCR request inhibit (MCRRI) flag, IV-1-2, XI-2-1
MCR system communication, IV-1-2
MCR task construction, XI-2-1
MCR terminal, VI-9-3
MCR timeout interval, XII-3-7
MDALLO macro, VI-B-2
MDDEAL macro, VI-B-3
MDGET macro, VI-B-3
MDPUT macro, VI-B-3
Memory management facilities, II-1-1
  extended, II-2-3
Memory,
  protection II-1-7, VII-6-7
  relocation, II-1-7

Memory-protect bound,
  raising, V-2-36
Memory size, xii-3-2
MFD, IV-2-36, IV-2-53, VI-3-1
MISCO, III-1-4, III-1-12,
    III-1-13
Miscellaneous,
  partitions, III-1-4
  sources, III-B-24
mnemonics, X-C-1
MNT, IV-2-36
MNT, TDV Function task, VII-16-1
  error messages, VII-16-1
Modifying core locations, V-2-57
Modifying VT-15 code, X-4-1
Monitor Console Routine (MCR),
    II-1-3, II-3-2, II-4-1,
    III-1-3
  function sources, III-B-1
Monitoring task progress, ODT,
    VII-22-6
MORE command, VIII-4-9
MOUNT, VI-8-12
Mount tape, VII-7-4
Mounting a disk, IV-2-36
Mounting a disk logically, VII-16-1
Mounting tape, VI-8-12
  unlabeled, VI-8-13
$MSG command, VIII-3-3
MT handler,
  request, VI-8-1
  task, VI-8-1
MTGET, VI-8-14
MTPUT, VI-8-16
MULTIACCESS, II-1-2, VI-1-2,
    VII-1-1, XII-3-6
  control-character facilities, VII-1-2.1
  Exit Processor, V-1-3
  Exit Queue (TDV.EQ), IX-2-26
  Monitor, II-1-3, III-1-5
  Monitor commands, VII-1-2.1
  shutting down, IV-2-62.1
Multiple batch jobs, VIII-6-7
Multiprogramming, real-time, II-1-5

N option, VII-7-3
Name of MCR function task,
    XI-2-1
NAME REGISTER, X-2-8
Name task option VII-6-8
Naming conventions, XI-1-2
NEW DECTAPE DIRECTORY, TDV Function
    task, VII-12-1
  error messages, VII-12-2
No parity check, VII-7-3
NODCNT, IV-2-59
Node,
  allocation, III-1-8
  analysis, III-1-8
  block size, IV-2-46
  contents, IV-2-17
  removal, IV-2-13
  sizes, III-1-8
Node, IX-1-1, IX-1-2, XI-1-2
  decreasing, III-1-4
  default assignment of, III-1-11
  deletion, III-1-11
  estimating number of, III-1-8,
    III-1-9
Nonprinting characters, X-2-6
Nonstandard display files, X-6-3

Object-Time System (OTS) library
    routines, VII-2-1
Obtaining exclusive use of device,
    VI-7-3
ODT, VII-22-1, XII-3-6
  commands, VII-22-2
  error messages, VII-22-10
  example, VII-22-6
  monitoring task progress,
    VII-22-6
  restrictions, VII-22-1
OFF command, VIII-4-5
OFFSET, X-2-8
ON command, VIII-4-5
On-line debugging, IV-2-37
On-line task development,
    II-3-2, II-4-2
OPEN, IV-2-37
  line terminators, IV-2-38
Open disk file, III-1-9
Operator,
  console, VIII-4-1
  interaction with BATCH, VIII-4-1
Opening file for input, VI-2-23,
    VI-3-10, VI-7-3
Opening file for output,
    VI-2-13, VI-3-10, VI-7-3
Operation of CR03B handler,
    VI-10-8
OPERATOR, IV-2-41
OPR,
  commands, VIII-4-1, VIII-4-3
  error messages, VIII-4-9, VIII-4-10
Optional characters, VII-1-9
Optional items, VII-1-10
Options,
  assembler, VII-3-2
  SLIP, VII-5-3
  $SLIP, VII-5-2
Organization of batch account file,
    VIII-5-1
OTS, V-2-65
  ASCII, VI-11-1
  error messages, VII-2-15
  error messages in FPP systems,
    VII-2-17
  output, VII-2-4
Overlay structure description,
    VII-6-15
Overlays, III-1-7
Overview of XVM/RSX system,
    II-4-1

Page eject, VII-7-4
Page-mode option, VII-6-7
Paper tape punch I/O, VI-13-1
  functions, VI-13-1
Paper tape reader I/O, VI-12-1
  functions, VI-12-1
Parameter input, MACRO
    assembler, VII-3-6
Parameters,
  assembly, III-B-1
  task building, III-B-1
PARINF, V-2-27
PARITY parameter, VI-9-2
Parity error message suppres-
    sion, VII-7-3
Partition, IV-1-1
  address, V-2-27
  blocks, IX-2-13
  description, VII-6-9
  DISPAT, III-1-5
  management, III-1-1
  miscellaneous, III-1-4
  size, V-2-27, VII-4-3, VII-6-7,
    VII-6-8, VII-6-9, XI-6-2,
    XII-4-2
  reconfiguration, III-1-7
Partition Block Description List
    (PBDL), III-1-8, III-1-9,
    IV-2-12, VII-6-9, IX-2-13,
    XI-6-2
Partitioned core, II-1-5
Partitions, IV-2-41, IV-2-46,
    IV-2-47
  reconfiguring, IV-2-49
  size, IV-2-49
  user, III-1-7
PASS1, PASS2, PASS3, VII-3-1
Password, XII-2-1
$PAUSE command, VIII-3-4
PAUSE statements, VII-2-4
PBDL, III-1-8
PDVL, VI-1-2, VI-4-1, VI-5-1
Permanent core space, III-1-11
Permanent system lists, III-1-8
Phosphor damage, X-2-9
Physical Device List (PDVL),
    III-1-9, IV-2-9, IV-2-27,
    IV,2-36, VI-1-2, IX-2-17,
    XI-4-2
Picture flickering, X-2-9
PIP, III-B-1
PLOT routine, X-3-1, X-3-2
Plotter, VI-18-1
PNAME, X-2-3
POINT subroutine, X-2-14, X-3-5
POLLER, IV-2-59
POOL, IX-1-2, IX-3-6
Pool of empty nodes, VII-6-7,
    XI-1-2
PP handler,
  request, VI-13-1
  task, VI-13-1
PR handler,
  request VI-12-1
  task VI-12-1
PRAMTR settings example, X-2-25
PRAMTR subroutine, X-2-7, X-3-4
PREAL, VI-2-19, VI-3-11
PREALlocate I/O directive, XI-6-2
Preallocating I/O buffers, VI-2-19,
    XI-6-1
  space, VI-3-11
Preconfigured system,
  saving, XII-3-7
Premature termination of MCR
  function task, IV-1-2, IV-2-14
Preparing to run BUILD, XII-3-1
Printing COMMON block
    definition, IV-2-14
Printing control lines,
    VIII-6-7
Printing current list of
    device units and LUNs,
    IV-2-23
Printing partition definitions,
    IV-2-42
Printing task descriptions,
    IV-2-70
Priority, IV-2-35
  calculation, VIII-6-5
  changing, IV-2-12
  default, VII-6-8
  tests, VIII-6-6
  time slicing, IV-2-63
Priority of task, II-1-4
Privileged mode, III-1-2
PROCEED command, VIII-4-6
Processing a directive, V-1-2
Program interrupt (PI), V-2-4
Prompting character (>), IV-1-1,
    IV-2-37
Prompting symbol (>), II-1-4
Protected mode, III-1-2
Protection, memory, II-1-7
PUP (Peripheral Utility
    Program), VII-1-1
PUT, VI-6-16, VI-7-6
PUT functions, X-7-1

QJOB, V-2-29, VIII-6-2
QUEUE,
  I/O, V-2-34, VI-2-3
  I/O directive, XI-4-1
QUEUE, TDV Function task,
    VII-21-1, VIII-6-1
  error messages, VII-21-3
Queuing batch job,
    V-2-29
Queuing I/O device requests,
    V-2-34
Queuing requests for a device,
    VI-2-3
$QUIT command, VIII-3-9

Radix default, IV-2-38
RAISEB, V-2-36

RAISEBound directive, XI-6-2
Raising memory-protect bound, V-2-36
Random-access file, VI-3-1, VI-3-3
Random-access information, VII-10-2
Random links
  establishing, VI-14-9
RASP SCOM words, IX-3-6
RBCD, VI-16-7
RBIN, VI-16-7
RCF, III-1-7, IV-2-45
RCP, III-1-7, IV-2-49
RDCOMP, VI-8-20
RDDI, VI-16-9, VI-16-11
READ, VI-2-20, VI-3-17, VI-7-3, VI-8-22, VI-9-7, VI-10-3, VI-12-3, VI-18-2, VIII-6-4
Read BCD, VI-16-7
Read binary, VI-16-7
READ macro, B-1
Read point, VI-16-8
Reading,
  buffer, VI-16-11
  from DECtape, VI-7-5
  from disk, VI-6-12
  from I/O device, VI-2-20
  from tape into user's buffer, VI-8-14
  input into buffer, VI-3-17, VI-7-3, VI-8-22, VI-9-7, VI-10-3, VI-12-3
  record, VI-8-20
  sequence of analog channels, VI-15-3
  tape label, VI-8-11
REASSIGN, IV-2-11, IV-2-51
REASSIGN, MCR Function task, XI-4-2
Real-time multiprogramming, II-1-5
Reconfiguration,
  dynamic, II-1-5
  partition, III-1-7
Reconfiguring core layout, IV-2-45
Reconfiguring partitions, IV-2-49
Record,
  comparing, VI-8-20
  reading, VI-8-20
Recoverable TKB errors, VII-6-20
Reenabling task, IV-2-30, V-2-14
REENTRANT ROUTINES FOR I/O HANDLER TASKS, IX-3-8
Reentrant system calls, IX-3-1
Reentrant system subrouines, XI-6-3
Register address, IV-2-37
Register, V-B-1, XI-1-2
RELEASE command, VIII-4-6
Relocatable mode, III-1-2
Relocation, memory, II-1-7
Relocation routines, X-6-1
Remote stimulus, VI-9-4
Removal of nodes, IV-2-13
REMOVE, IV-2-25, IV-2-54
REMOVE, TDV Function task, VII-15-1
  error messages, VII-15-2
Remove-on-exit bit, IV-2-32
RENAME, VI-2-21
RENAME FILE, TDV Function task, VII-9-1
  error messages, VII-9-2
RENAME macro, VI-B-5
Renaming file, VI-2-21
REPLACE, VII-5-8
REPLACE WITH FILE, VII-5-9
Replacing RSX Executive, XII-A-1
REPLOT routine, X-4-2
REQUEST, IV-2-55, VI-2-37
  faster response, IV-2-34
  rejection, IV-2-25
REQUEST MAPPED, V-2-35.1
REQUEST system directive, IV-1-1
REQUEST, TDV Function task, VII-14-1
  error messages, VII-14-2
Requesting a task with mapped LUNs, V-2-35.1
Requesting driver task information, VI-6-4
Requesting handler task information, VI-3-10, VI-7-2, VI-9-5, VI-10-2, VI-11-2, VI-12-2, VI-13-2, VI-14-2, VI-15-2, VI-16-2, VI-17-2, VI-19-1
Requesting I/O handler information, VI-2-15, VI-8-3
Requesting task execution, IV-2-55
  from user disk, IV-2-32, V-2-16
Reserving storage, VI-6-6
Reschedule interval ranges, V-2-24, V-2-42, V-2-60
Resident code definition, VII-6-13
Resident MCR task, IV-1-1, IV-2-59
  execution of, IV-1-1
RESIDENT MONITOR CONSOLE ROUTINE (MCR), II-1-3, II-3-2
Resident task development (TDV), II-1-3
Resident TDV Dispatcher, VII-1-7
Restore operations, V-B-1
Restrictions, X-2-1
RESUME, IV-2-56, V-2-40
Resuming task execution, IV-2-56
Retrieving time and date, V-2-8
Returned event variables, V-4-3, VI-A-2
Returning name of issuing task, V-2-65
Returning partition address and size, V-2-27
REWIND, VI-8-24
Rewinding tape, VI-8-24
RF disk handler, III-1-4
RF disk I/O, VI-3-1
  functions, VI-3-9
RF handler,
  requests, VI-3-8
  structure, VI-3-7
  Task, VI-3-1
RK disk handler, III-1-4
RK disk I/O, VI-4-1

RK handler task, VI-4-1
ROTATE, X-2-8
ROTATE subroutine, X-2-16
  example, X-2-26
RP disk handler, III-1-4
RP disk I/O, VI-5-1
RP handler task, VI-5-1
RSETPT routine, X-4-3
RSX devices, XI-4-3
RSX system lists, IX-2-2
RSX Task Builder (TKB), XII-3-2
RSXIMG, IV-2-59
Rubout, IV-1-3, VII-1-9
RUN, IV-2-57, V-2-42
  faster response, IV-2-34
  rejection, IV-2-25
Runing batch job file, XII-3-4, XII-3-7
Running BUILD, XII-3-1

Sample batch processing sequence, VIII-1-1
SAVE, IV-2-59
Save operations,
  registers, V-B-1
SAVE-REMOVE-INSTALL system file, IV-2-54, IV-2-60
SAVE-RESTORE option, X-2-7
Saving preconfigured system, XII-3-7
SCALE (picture size), X-2-7
SCHEDULE, IV-2-61, V-2-7
  faster response, IV-2-34
  rejection, IV-2-25
SCHEDULE command, VIII-4-4, VIII-6-3
Scheduling,
  task, II-1-3
  task execution, IV-2-61, V-2-47
SCOM (System Communications Area), IX-2-1, IX-3-1
Scope images, storae of, X-6-1
SEARCH AND INSERT, VII-5-10, VII-5-11
SEARCH AND REPLACE, VII-5-12
SEARCH AND REPLACE WITH FILE, VII-5-13
SEEK, VI-2-23, VI-3-10, VI-7-3
SEEK macro, VI-B-4
Semipermanent core space, III-1-13
Separators, IV-1-3
Sequential-access file, VI-3-1, VI-3-2
Sequential files transfer, VII-7-1
Sequential links,
  establishing, VI-14-6
Set system clock and calendar, IV-2-31
SETJEA, V-2-52
SETPT routine, X-3-1, X-3-2
Setting and event variable, V-2-24
Setting pointers, IV-1-2
SHARE, V-2-53
Shared address space (SAS), VII-6-10, VII-6-11
  external (ESAS), VII-6-11
  internal (ISAS), VII-6-11
Shared COMMON block description, VII-6-10, VII-6-11
SHUT, IV-2-62.1
Shutting down MULTIACCESS, IV-2-62.1
Sign default, IV-2-38
Significant event, II-1-4
Significant event declaration, VI-14-3
Sine wave program example, X-2-20, X-2-21, X-2-22
Sine wave program written for single display file, X-2-23
.SIXBT character set, V-C-1
Size,
  core, III-A-1
  disk I/O buffer III-1-8
  node, III-1-8
  user task, III-1-7
SIZE command, VII-4-3
SLICE, IV-2-63
SLIP, II-3-3, VII-5-1
  command syntax errors, VII-5-16
  control records, VII-5-4
  editing demonstration, VII-5-16
  error messages, VII-5-14
  options, VII-5-3
  sequencing errors, VII-5-16
$SLIP,
  control record errors, VII-5-15
  options, VII-5-2
Small Node Description List (SNDL), III-1-9, IX-2-20
Software, II-1-3
  capabilities, II-3-1
  modules, II-1-3
Source files, X-9-1
Source programs, VII-3-1
Space, IV-1-2, VII-1-10
Space, allocation, X-2-3
Space character, VII-7-2
Special BATCH commands, VIII-2-2, VIII-3-1
Spacing forward,
  files, VI-8-9
  records, VI-8-10
Spacing forward to EOT, VI-8-8
Specifying environment, XII-4-3
Specifying tape format, VI-8-6
SPY, V-2-55
SPYREL, V-2-55
SPYSET, V-2-57
Square brackets, ([]), VII-1-10, X-2-5
Starting AD conversion, VI-14-12
Starting block number, VII-10-2
STATUS, TDV Function task, VII-23-1

STOP command, VIII-4-8
STOP Statements, VII-2-4
Stopping AD conversion, VI-14-12
Storage of display file, X-2-2
Storage of scope images, X-6-1
Storage overhead, X-2-3
STROBE, IV-2-66
Strobe system deques, IV-2-66
Structures description VII-6-13
Subpicture routines, X-2-1
Subroutines calling conventions, X-2-2
Subroutines, XI-6-3
Summary of routines, X-B-1
SUSPEND, V-2-59
SUSPENDING TASK EXECUTION, V-2-59
SYMBOL TABLE, VII-3-1
SYNC (synchronization), X-2-9
SYNC, IV-2-68, V-2-60
  faster response, IV-2-34
  rejection, IV-2-25
Synchronizing task execution, IV-2-68, V-2-60
System backup, IV-2-59
System blocks, VII-11-1
System build procedures, XII-6-1
System COMMON blocks, III-1-2, IV-2-46
System COMMON blocks description, VII-6-10
System COMMON Blocks Description List (SCDL), IX-2-19
System Communications Area (SCOM), IV-1-2, IX-2-1
System configuration, XII-4-1
System deque listheads, IX-3-6
System deques,
  list, IV-2-66
  listing, IV-2-17
  strobe, IV-2-66
System directive abbreviations, V-4-2
System directives, V-2-1
  table of V-1-4
System error log, IX-3-3
System library, VII-6-13
System lists,
  permanent, III-1-8
  transient, III-1-8
System lists and organization, II-4-2
System macros, V-3-1
System management, II-4-1, VIII-5-1
System organization, III-1-1
System parameters, IX-3-2
System pointers, IX-3-1
System program,
  core size, III-A-1
System resources, XI-1-2, XI-4-2
System status, VII-23-1
System subroutines, XI-6-3
System Task List (STL), II-1-4, III-1-9, IV-2-2, IV-2-12, IV-2-60, IX-2-21
System tasks, III-1-14
System transients, III-1-14
System reconfiguration, on-line, II-1-1

TABLE INITIALIZATION, VII-2-4
Tape,
  dismounting, VI-8-12, VI-8-13
  mounting, VI-8-12
Tape label,
  read, VI-8-11
  write, VI-8-11
Task,
  aborting I/O for ,VI-2-5, VI-6-5
  activating execution, V-2-42
  activation, II-1-4
  adding, IV-2-35
  breakpoints, VII-22-1
  cancelling request for, IV-2-13
  deleting, IV-2-54
  disabling, IV-2-25, V-2-10
  exit, VI-1-3
  fixing, IV-2-34, V-2-22
  installing, IV-2-15
  reenabling, IV-2-30, V-2-14
  requesting execution, V-2-37
  requesting execution from user disk, V-2-16
  resuming execution, V-2-40
  returning name of, V-2-65
  scheduling execution, V-2-47
  size, V-2-36
  suspending execution, V-2-59
  synchronizing execution, V-2-60
  terminating execution, V-2-19
Task Builder, II-3-3, VII-6-1
  input/output, VII-6-4
  options, VII-6-5
Task building,
  CONSTRUCT, VII-19-1
  DECTAPE DIRECTORY LIST, VII-11-2
  DELETE FILE, VII-8-1
  DIRECTORY LIST, VII-10-2
  DISMOUNT, VII-17-1
  FILE INPUT, VII-7-3
  INSTALL, VII-13-1
  MOUNT, VII-16-1
  NEW DECTAPE DIRECTORY, VII-12-1
  parameters, III-B-1
  QUEUE, VII-21-3
  REMOVE, VII-15-1
  RENAME FILE, VII-9-2
  REQUEST, VII-14-1
  STATUS, VII-23-1
Task development functions (TDV), II-3-3, III-1-5, VII-1-1
  partitions, III-1-5
  sources, III-B-9
Task development, on-line, II-3-2
Task execution, II-1-3.1, II-1-5
  activating, IV-2-57
  requesting, IV-2-32, IV-2-55
  resuming, IV-2-56
  scheduling, IV-2-61
  suspending, IV-2-56
  synchronizing, IV-2-68

Task exit, IX-3-7, XI-1-2
Task interruption, II-1-5
Task level, II-1-4
Task list, IV-2-70
  active, II-1-4
  system, II-1-4
Task name, VII-6-8
Task priority, XI-4-2
Task scheduling, II-1-3
  example, II-1-5, II-1-6
Task size, user, III-1-7
Task Termination Notice
    Request List (TNRL),
    III-1-9, V-1-3, IX-2-24
Task size, XI-6-2
Task status, IX-2-4
Task storage on disk, VI-19-1
Tasks, II-1-3
  adding, XII-5-1
  system, III-1-14
TDV command conventions,
    VII-1-9
TDV command line,
  transferring, V-2-73
TDV error messages, VII-7-5
TDV function task example,
    XI-3-3
TDV function tasks, VII-1-2, VII-1-9
TDV/system communication,
    VII-1-8
TDV task construction, XI-3-1
TDV terminal, VI-9-4
Terminal characteristics,
    VI-9-1
Terminal handler parameters,
    IX-3-4
Terminal handler task, IV-1-2
Terminal I/O, VI-9-1
  functions, VI-9-4
Terminals, XII-3-7
  supported, IV-2-29
Terminating batch processing, VIII-2-3
Terminating task execution,
    V-2-19
  (terminator), VII-1-10
Terminators, command string,
    VII-1-9
Text Editor, II-3-3
  other versions of, VII-4-3
Text-editing source code,
    VII-4-1
Text string rotation, X-2-8
TEXT subroutine, X-2-5, X-3-4
Time,
  entering, IV-2-31
  retrieving, IV-2-16
Time interval ranges, IV-2-57,
    IV-2-61, IV-2-68
Time limit options, VIII-4-8
Time slicing, II-1-2
  initiating, IV-2-63
  priority range, IV-2-63
TIMFLG, V-2-20
Time values, IX-3-3
TKB, XII-3-2, XII-3-6
TKB errors, VII-6-19
  recoverable, VII-6-20
  unrecoverable, VII-6-21
TLACT command, VIII-4-8
TNTERN, V-1-3
Tracking, X-5-2
TRACK routine, X-5-5
Transferred files, VII-7-3
Transferring data from COMMON
    block to task, VI-17-3
Transferring data from task to
    COMMON block, VI-17-5
Transferring TDV command line,
    V-2-73
Transient,
  queues, III-1-8
  system tasks, III-1-14
Trigger event variable, XI-4-2
Truncation, X-2-5, X-2-11, X-3-2
Truncation mark, VII-10-2
TSK files, XII-3-3
TSKNAM, V-2-65
TTY handler,
  requests, VI-9-4
  task, VI-9-1
TYPE, TDV Function task, VII-7-1
Type-in, VI-9-3

UC15,
  errors, VI-10-5
  operation, VI-10-4, VI-11-3
UDC I/O functions, VI-16-2
UF handler,
  requests, VI-16-1
  task, VI-16-1
UFD, VI-3-1, VI-3-4, VII-16-1
Unassigned LUNs, IV-2-23
UNBLNK subroutine, X-2-14
UNFIX, IV-2-73, V-2-67
Unichannel,
  configuration, II-2-5
  support, I-2-5
Unichannel hardware, XII-3-4
Unichannel operation, VI-18-4
Unichannel space, III-1-6
UNIVERSAL DIGITAL CONTROLLER I/O,
    VI-16-1
  functions, VI-16-2
Unloadng tape, VI-12-7
UNMARK, V-2-69
Unpacking and event variable,
    VI-6-20
Unrecoverable TKB errors,
    VII-6-21
UPKEV, VI-6-20
Upper-case characters, VII-1-10
Use and allocation of I/O
    buffers, XI-6-1
Use of BATCH, VIII-1-1
User,
  files, VII-11-1
  partitions, III-1-7
  task size, III-1-7

User disk,
  dismount, IV-2-27
  execution from, IV-2-32
User file directory (UFD),
    VI-3-4
User mode, III-1-2, III-1-7,
    XI-3-1
  core space, III-1-11
  option, VII-6-7
User recovery, VI-8-17
Utility functions, II-3-3

Virtual LUNs, V-2-18, V-2-34, VI-1-2
Virtual partition size,
    VII-6-10, XI-6-2
VT15 handler, X-D-1
VTUNIT routine, X-5-2

WAIT, V-2-70
WAIT command, VIII-4-6
WAITFOR, V-2-71
Waiting for event variable,
    V-2-71
Waiting for next significant
    event, V-2-70
WREOF, VI-8-25
WRITE, VI-2-25, VI-3-18, VI-7-3
    VI-8-26, VI-9-9, VI-11-3,
    VI-13-3, VI-18-3, VI-19-2, VIII-6-4
WRITE macro, VI-B-1
Writing end-of-file mark, VI-8-25
Writing output from buffer,
    VI-3-8, VI-7-3, VI-8-26,
    VI-9-9, VI-11-3, VI-13-3,
    VI-19-2
Writing tablet example, X-8-3
Writing tablet handler, X-8-1
Writing tape label, VI-8-11
Writing to DECtape, VI-7-6
Writing to disk, VI-6-16
Writing to I/O device, VI-2-25
Writing to tape from user's
    buffer, VI-8-16

XFRCMD system directive,
    V-2-73, VII-1-9
XVM hardware, XII-3-6
XY handler,
  requests, VI-18-1
  task, VI-18-1
XY plotter I/O, VI-18-1
  functions, VI-18-1

XVM/RSX
System Manual
DEC-XV-IRSMA-A-D

READER'S COMMENTS

NOTE: This form is for document comments only. Problems with software should be reported on a Software Problem Report (SPR) form.

Did you find errors in this manual? If so, specify by page.

_____

_____

_____

_____

_____

_____

Did you find this manual understandable, usable, and well-organized? Please make suggestions for improvement.

_____

_____

_____

_____

_____

_____

Is there sufficient documentation on associated system programs required for use of the software described in this manual? If not, what material is missing and where should it be placed?

_____

_____

_____

_____

_____

_____

Please indicate the type of user/reader that you most nearly represent.

- ☐ Assembly language programmer
- ☐ Higher-level language programmer
- ☐ Occasional programmer (experienced)
- ☐ User with little programming experience
- ☐ Student programmer
- ☐ Non-programmer interested in computer concepts and capabilities

Name _____ Date _____

Organization _____

Street _____

City _____ State _____ Zip Code or Country _____

If you require a written reply, please check here. ☐

Please cut along this line.

---------- Fold Here ----------

---------- Do Not Tear - Fold Here and Staple ----------

FIRST CLASS
PERMIT NO. 33
MAYNARD, MASS.

BUSINESS REPLY MAIL
NO POSTAGE STAMP NECESSARY IF MAILED IN THE UNITED STATES

Postage will be paid by:

digital

Software Communications
P. O. Box F
Maynard, Massachusetts 01754